

ACCOPPIAMENTO VALVOLE E DETENTORI



<u>valvola</u>	<u>detentore</u>	<u>raccordi rame</u>	<u>raccordi multistrato</u>	<u>valvola termost.</u>	<u>comando termost.</u>
433-1300V-	433-1300D-				
433-1301V-	433-1301D-				
433-1408V-	433-1408D-				
433-1403V-	433-1403D-	* 433-1403R-...(Pz 2)	* 433-1403M-...(Pz2)		
433-1302V-	433-1302D-	* 433-14AB-...(Pz 2)	* 313-1635-...(Pz2)		
433-140A-	433-140B-	* 433-14AB-...(Pz 2)	* 313-1635-...(Pz2)		
	433-1402D-	* 433-14AB-...(Pz 2)	* 313-1635-...(Pz2)	433-1402V-	433-1420/1421
	433-1404D-	* 433-14AB-...(Pz 2)	* 313-1635-...(Pz2)	433-1404V-	433-1420/1421
	433-1401D-			433-1401V-	433-1420/1421

* n.b i raccordi vanno scelti in base al tipo di materiale utilizzato dall' idraulico per l' impianto, pertanto o RAME o MULTISTRATO